DIRECTED.

Directed Passive Keyless Entry System (PKE)

Model 2102T

Owner's Guide

Contents

Government regulations	4
Warning! Safety first	6
Important information	6
System maintenance	
Maximize the performance of your system	6
Using the system	
Automatic unlocking and locking of the vehicle	7
Manual unlocking and locking of the vehicle	7
Enabling/Disabling valet mode	8
Sleep mode	
SmartLock Feature	10
Glossary of terms	13
Limited lifetime consumer warranty	14

Government regulations

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, which can be determined by turning the equipment Off and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

To satisfy FCC RF exposure compliance requirements, this device should be used in hand-held, hand operated configurations only. This device is designed to be used in a person's hands and its operating configurations do not support normal transmissions while it is carried in pockets or holsters next to a persons' body.

This device complies with the Industry Canada Radio Standards Specification RSS 210. Its use is authorized only on a no-interference, no-protection basis; in other words, this device must not be used if it is determined that it causes harmful interference to services authorized by IC. In addition, the user of this device must accept any radio interference that may be received, even if this interference could affect the operation of the device.

Warning:

The installation of this product must only be performed by technicians who are trained or certified by Directed dealers. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

⚠Warning! Safety first

The following safety warning must be observed at all times: Due to the complexity of this system, installation of this product must only be performed by an authorized Directed dealer.

Important information

Congratulations on the purchase of your state-of-the-art Passive Keyless Entry System (PKE). Due to the complexity of this system, it must be installed by an authorized dealer only. Installation of this product by anyone other than an authorized dealer voids the warranty. All dealers are provided with a preprinted dealer certificate to verify authorization.

By carefully reading this Owner's Guide prior to using your system, you will maximize the use of this system and its features. You can print additional or replacement copies of this manual by accessing our web site at www.xpresskit.com.

System maintenance

The system requires no specific maintenance. Your remote is powered by a small coin cell lightweight 3-volt lithium battery (CR2032) that lasts approximately 3 years under normal use. When the battery begins to weaken, the operating range is reduced.

Maximize the performance of your system

Never put the key fob together with a cellphone as this may affect the range and its performance.

A third antenna can be installed to extend the range of the active zone. The installation must be done by technicians who are trained or certified by Directed dealers (optional parts and extra labor required). Refer to your authorized dealer for more information.

Using the system

Automatic unlocking and locking of the vehicle

Passive door unlocking

The key fob LED will start flashing green once you have entered the active zone. The doors will be automatically unlocked and the starter kill (optional) will be disarmed.

Note: The unlock operation may be delayed when approaching the vehicle immediately after a remote start command has been sent.

Passive door locking

The key fob LED will start flashing red once you have left the active zone. The doors will be automatically locked and the starter kill (optional) will be armed. The key fob LED will turn ON solid red for 1 second to confirm when the doors have been locked.

Starter kill output (optional)

When the optional starter kill feature is installed and active, it will interrupt the starter wire of the vehicle when doors are locked; thus preventing vehicle theft by not allowing the vehicle to be started.

Note: This feature is optional and must be configured by the installer (optional parts and extra labor required).

The optional starter kill is disabled as soon as the doors are unlocked by the PKE system. It can also be disabled with a toggle switch installed somewhere in the vehicle. Refer to your authorized dealer for the location.

Manual unlocking and locking of the vehicle

Although the PKE system allows for automatic locking and unlocking of the vehicle when you approach and leave the active zone, it also offers the flexibility of manually locking and unlocking doors with the remote.

Manual unlocking

Press and hold the button until the LED on the remote flashes red. The parking lights will flash twice to confirm the doors have been unlocked.

Manual locking

Press and release the button for 1 second. The LED on the remote will flash red indicating that the command is being sent, and the parking lights will flash once to confirm the doors have been locked.

Note: When installed with certain remote starter models, the doors might not locks when the vehicle is running by the key.

Enabling/Disabling valet mode

Valet mode can be enabled and disabled using the following procedure. When the feature is enabled, the automatic locking/unlocking operation upon entering the active zone will be disabled. However, manual locking/unlocking of the vehicle is possible in valet mode, as long as the ignition is off.

Enable valet mode

Within the active zone, quickly press and release the key fob button twice, then press and hold until the remote LED flashes red to confirm the system has entered valet mode. The key fob LED will no longer flash to indicate whether you are in the active zone or not.

Disable valet mode

Within the active zone, quickly press and release the key fob button twice, then press and hold until the remote LED flashes red to confirm the system has exited valet mode. The key fob LED will flash to indicate whether you are in the active zone or not.

Sleep mode

For security reasons, your PKE system is in sleep mode while the vehicle is in motion.

Turning the sleep mode ON

In order to prolong the key fob battery life, the PKE system will enter sleep mode once the user is in the vehicle, all the doors are closed and the brake pedal is depressed (a valid key fob must be inside the vehicle).

Warning: Failure to execute these steps, while the key fob is present in the vehicle, may cause its battery to be drained prematurely, and consequently your keys may become locked inside the vehicle.

Turning the sleep mode OFF

The PKE system will exit sleep mode and will return to normal operation when a door is opened.

Note: This feature is automatically enabled/disabled every time vehicle is in use. It does not affect the user's experience.

SmartLock Feature

The purpose of the SmartLock feature is to prevent the doors from unwanted unlocking/locking when entering/exiting the active zone multiple times for a pre-programmed delay (No delay*, 1, 3 or 5 minutes). This is practical in situations such as loading/unloading packages.

*SmartLock feature is disabled when it is set to no delay, which is only configurable by your authorized dealer.

Note: If the Door Open Interlock feature is enabled, the SmartLock feature will not be able to lock a door when it is left opened.

To use the SmartLock feature, the following sequence must be performed:


- Exit the active zone with the valid key fob in hand. This action will lock the doors and initiate the pre-programmed timer.
- Re-enter the zone within the pre-programmed delay (1, 3 or 5 minutes)
 to activate the SmartLock feature. As long as you are still within the preprogrammed delay and have the valid key fob in hand, the doors will
 unlock.
- At this point, the SmartLock timer is reset and frozen. If you exit the zone with the valid key fob, the doors will not lock and a fresh timer will start.
- Again, if you re-enter the zone within the pre-programmed delay, the doors will not unlock since the door is already unlocked from step 2.
- If step 3 and 4 are repeated many times, the lock/unlock operation will
 never occur thus making it convenient during loading/unloading, as long
 as the doors are not opened or closed during the whole sequence.
- 6. Once the valid key fob remains out of the active zone longer than the pre-programmed delay, the doors will automatically lock. At this point, the Smartlock feature will be disabled. It is important to note that the user can always lock the doors immediately at any moment by quickly pressing and releasing the key fob button (See "Manual unlocking and locking of the vehicle" on page 7).

Note: If the doors are opened or closed at any point between steps 3 and 4, the SmartLock feature will be cancelled causing the doors to be locked as soon as the key fob exits the active zone. To use SmartLock again, you must reenter the active zone with the valid key fob in hand within the pre-programmed delay once the doors are locked.

The following will cancel the SmartLock feature:

- Pre-programmed timer has elapsed.
- Any manual Lock/Unlock command is sent using the key fob.
- A door is closed/opened; however, the trunk does not impact the SmartLock feature.

SmartLock feature



Glossary of terms

Key Fob: The functions of the Passive Keyless Entry (PKE) system are contained on a key fob or built into the ignition key handle itself. A key fob is by definition a key chain.

LED: A light used to indicate the status of your system. It is located on your remote.

PKE: Passive Keyless Entry.

Starter Kill: An interrupt controlled by the PKE system which prevents the vehicle's starter from cranking whenever the system is locked.

Limited lifetime consumer warranty

Directed promises to the original purchaser to repair or replace (at Directed's election) with a comparable reconditioned model any Directed unit (hereafter the "unit"), excluding without limitation the siren, the remote transmitters, the associated sensors and accessories, which proves to be defective in workmanship or material under reasonable use during the lifetime of the vehicle provided the following conditions are met: the unit was purchased from an authorized Directed dealer, the unit was professionally installed and serviced by an authorized Directed dealer; the unit will be professionally reinstalled in the vehicle in which it was originally installed by an authorized Directed dealer; and the unit is returned to Directed, shipping prepaid with a legible copy of the bill of sale or other dated proof of purchase bearing the following information: consumer's name, telephone number and address; the authorized dealers name, telephone number and address; complete product description, including accessories; the year, make and model of the vehicle; vehicle license number and vehicle identification number. All components other than the unit, including without limitation the siren, the remote transmitters and the associated sensors and accessories, carry a one-year warranty from the date of purchase of the same. ALL PRODUCTS RECEIVED BY DIRECTED FOR WARRANTY REPAIR WITHOUT PROOF OF PURCHASE WILL BE DENIED. This warranty is non-transferable and is automatically void if: the original purchaser has not completed the warranty card and mailed it within ten (10) days from the date of purchase to the address listed on the card; the unit's date code or serial number is defaced, missing or altered; the unit has been modified or used in a manner contrary to its intended purpose; the unit has been damaged by accident, unreasonable use, neglect, improper service, installation or other causes not arising out of defects in materials or construction. The warranty does not cover damage to the unit caused by installation or removal of the unit. Directed, in its sole discretion, will determine what constitutes excessive damage and may refuse the return of any unit with excessive damage.

TO THE MAXIMUM EXTENT ALLOWED BY LAW, ALL WARRANTIES, INCLUDING BUT NOT LIMITED TO EXPRESS WARRANTY, IMPLIED WARRANTY, WARRANTY OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE AND WARRANTY OF NON-INFRINGEMENT OF INTELLECTUAL PROPERTY, ARE EXPRESSLY EXCLUDED; AND DIRECTED NEITHER ASSUMES NOR AUTHORIZES ANY PERSON OR ENTITY TO ASSUME FOR IT ANY DUTY, OBLIGATION OR LIABILITY IN CONNECTION WITH ITS PRODUCTS. DIRECTED DISCLAIMS AND HAS ABSOLUTELY NO LIABILITY FOR ANY AND ALL ACTS OF THIRD PARTIES INCLUDING ITS AUTHORIZED DEALERS OR INSTALLERS. DIRECTED SECURITY SYSTEMS, INCLUDING THIS UNIT, ARE DETERRENTS AGAINST POSSIBLE THEFT. DIRECTED IS NOT OFFERING A GUARANTEE OR INSURANCE AGAINST VANDALISM, DAWAGE OR THEFT OF THE AUTOMOBILE, ITS PARTS OR CONTENTS; AND HEREBY EXPRESSLY DISCLAIMS ANY LIABILITY WHATSOEVER, INCLUDING WITHOUT LIMITATION, LIABILITY FOR THEFT, DAMAGE AND/OR VANDALISM. THIS

Warranty does not cover labor costs for maintenance, removal or REINSTALLATION OF THE UNIT OR ANY CONSEQUENTIAL DAMAGES OF ANY KIND. IN THE EVENT OF A CLAIM OR A DISPUTE INVOLVING DIRECTED OR ITS SUBSIDIARY. THE VENUE SHALL BE SAN DIEGO COUNTY IN THE STATE OF CALIFORNIA. CALIFORNIA STATE LAWS AND APPLICABLE FEDERAL LAWS SHALL APPLY AND GOVERN THE DISPUTE. THE MAXIMUM RECOVERY UNDER ANY CLAIM AGAINST DIRECTED SHALL BE STRICTLY LIMITED TO THE AUTHORIZED DIRECTED DEALER'S PURCHASE PRICE OF THE UNIT. DIRECTED SHALL NOT BE RESPONSIBLE FOR ANY DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO, ANY CONSEQUENTIAL DAMAGES. INCIDENTAL DAMAGES. DAMAGE TO VEHICLE. DAMAGES FOR THE LOSS OF TIME. LOSS OF EARNINGS, COMMERCIAL LOSS, LOSS OF ECONOMIC OPPORTUNITY AND THE LIKE, NOTWITHSTANDING THE ABOVE, THE MANUFACTURER DOES OFFER A LIMITED WARRANTY TO REPLACE OR REPAIR THE CONTROL MODULE SUBJECT TO THE CONDITIONS AS DESCRIBED HEREIN. THIS WARRANTY IS VOID IF THE UNIT HAS NOT BEEN PURCHASED FROM DIRECTED, OR AN AUTHORIZED DIRECTED DEALER. OR IF THE UNIT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE. NEGLIGENCE, ACTS OF GOD, NEGLECT, IMPROPER SERVICE, OR OTHER CAUSES NOT ARISING OUT OF DEFECT IN MATERIALS OR CONSTRUCTION

Some states do not allow limitations on how long an implied warranty will last or the exclusion or limitation of incidental or consequential damages. This warranty gives you specific legal rights and you may also have other rights that vary from State to State.

This warranty is only valid for sale of product(s) within the United States of America. Product(s) sold outside of the United States of America are sold "AS-IS" and shall have NO WARRANTY, express or implied. This product may be covered by a Guaranteed Protection Plan ("GPP"). See your authorized Directed dealer for details of the plan or call Directed Customer Service at 1-800-876-0800.

Make sure you have all of the following information from your authorized Directed dealer: A clear copy of the sales receipt, showing the following:

- Date of purchase
- Your full name and address
- Authorized dealer's company name and address
- Type of alarm installed
- Year, make, model and color of the automobile
- Automobile license number
- Vehicle identification number
- All security options installed on automobile
- Installation receipts

920-0003 06-06

The company behind this system is Directed

Since its inception, Directed has had one purpose, to provide consumers with the finest vehicle security and car stereo products and accessories available. The recipient of nearly 100 patents and Innovations Awards in the field of advanced electronic technology.

Directed is ISO 9001 registered.

Quality Directed products are sold and serviced throughout North America and around the world.

Call (800) 274-0200 for more information about our products and services.

Designed and Engineered in the USA



G2102T 2012-07-18

Vista, CA 92081 www.directed.com © 2012 Directed—All rights reserved